

REGLAZING INSTRUCTIONS

Series 800 - Casement Window - Tools required - #2 Phillips screwdriver
Materials - 1" Insulated Glass Unit

*** REMOVE SCREWS FROM HINGES**

*** WITH THE SASH ON A FLAT SURFACE**

REMOVE (2) PHILLIPS SCREWS AT EACH SIDE OF THE SASH, WHERE THE TOP RAIL MEETS THE STILES (sides).

LOOSEN THE REMAINING SCREWS AT THE OPPOSITE CORNERS

REMOVE THE TOP RAIL SECTION OF THE SASH AND SPREAD THE TWO STILES

REMOVE THE IG UNIT AND THE WRAP-AROUND GLAZING.

*** REPLACE THE IG UNIT WITH WRAP-AROUND GLAZING.**

REVERSE ABOVE PROCEDURE