

REGLAZING INSTRUCTIONS for SINGLE PANE

Series 825 - Project-out Window-

Tools required - Putty knife or other thick blade, hammer or mallet, broad blade putty knife, glass cup (optional/recommended)

Materials required – Glass Unit (GU)

- 1/8” Butyl Tape, setting blocks (re-use existing when possible)

\* Remove Glass Unit

- remove the glazing bead/glass stop by separating and simultaneously prying away from the main frame starting at the jamb pieces.
- remove the GU by prying the glass from the glazing leg (start at an outside corner using constant pressure (the assistance of a glass cup is recommended))
- remove the existing butyl tape from the glazing leg
- place new butyl tape at the glazing leg
- replace existing setting blocks in current location (or use new)
- center the GU in the opening, resting on the setting blocks
- press the GU firmly and continuously along the Butyl Tape
- replace the glazing bead/glass stop
- clean the glass