

REGLAZING INSTRUCTIONS

Series 925 - Project-out Window-

Tools required - Putty knife or other thick blade, hammer or mallet, broad blade putty knife, glass cup (optional/recommended)

Materials required – 7/8” Insulated Glass Unit (IGU)

-- 1/8” Butyl Tape, setting blocks (re-use existing when possible)

* Remove Insulated Glass Unit

- remove the glazing bead/glass stop by separating and simultaneously prying away from the main frame starting at the jamb pieces.

- remove the IGU by prying the glass from the glazing leg (start at an outside corner using constant pressure (the assistance of a glass cup is recommended)

- remove the existing butyl tape from the glazing leg

- place new butyl tape at the glazing leg

- replace existing setting blocks in current location (or use new)

- center the IGU in the opening, resting on the setting blocks

- press the IGU firmly and continuously along the Butyl Tape

- replace the blazing bead/glass stop

- clean the glass