

MANUFACTURER'S INSTALLATION INSTRUCTIONS FOR SLIDING GLASS DOORS

*Doors shall be securely anchored in place to a straight, plumb and level condition without distortion.

*Doors shall be attached with minimum #8 non-rust-plated screws (larger as required by project conditions) at the:

- a)Head - 2" from each end and at 16" centers.
- b)Jambs - 2" from each end and at 16" centers.
- c)Sill- (per job conditions)

Note: Care shall be taken not to place fasteners in any area that might interfere with the proper operation and sealing of the door. Fasteners must be installed so as not to cause the door to warp or bind.

*Location of fasteners is dependent upon the alignment of the door framing and the available area for attachment. Typically, two fasteners at head, each jamb, and at sills (if required) are suitable. Specific job conditions may warrant different fastening locations and systems.

*Doors shall be blocked and shimmed as needed to provide a sound surface for installation.

*Door perimeters shall be sealed at the exterior and interior with the approved caulking compound.

*Door shall be checked for proper operation and necessary adjustments made to insure proper operation.